

# The *Standard Horizon HX300* programming interface

© Torkel M. Jodalén  
*annoyingdesigns.com*

June 18, 2015

## Abstract

This document describes the electrical characteristics of the programming interface utilized by the *Standard Horizon HX300* floating handheld VHF radio. Two examples of programming interfaces are provided.

The *CE134* programming software will still be required for programming the radio.



*The Standard Horizon HX300.*

## Disclaimer

The sole purpose of this document is to provide owners of the *Standard Horizon HX300* handheld VHF radio with information on how to make the most out of their units.

While the *Standard Horizon HX300* radio may come with relevant end-user documentation included, details regarding the programming interface are indeed sadly lacking.

The author does not represent any manufacturer of software products or hardware units mentioned in this document. Likewise, the author does not have any commercial interests in any of the companies or products mentioned in this document. The author happens to own and use a *Standard Horizon HX300*, though.

All trademarks remain the property of their respective holders, and are used only to identify the products mentioned. Their use in no way indicates any affiliation between the author and the holders of the said trademarks.

The author assumes no responsibility for your use of information contained in this document. The information in this document has been used to successfully program a *HX300E* unit.

NOTE: Consult your national legislation regarding radio frequency usage before programming the *Standard Horizon HX300*. National legislation may limit your rights to add user channels to the radio. Never transmit on frequencies on which you are not licensed to operate.

## Contents

1	Introduction	2
1.1	The <i>Standard Horizon HX300</i> floating handheld VHF radio . . . . .	2
1.2	The original <i>HX300</i> programming interface . . . . .	3
2	The <i>HX300</i> USB interface	4
2.1	A brief examination of the <i>HX300</i> mini-USB connector . . . . .	5
2.2	Option 1: Using the <i>USB-62B</i> and the <i>CT-99</i> cable assemblies . . . . .	6
2.3	Option 2: Connecting to the <i>FTDI Friend</i> (and the likes) . . . . .	7
3	<i>HX300</i> programming software	9
3.1	The <i>CE134</i> PPS programming software . . . . .	9
3.2	DIY programming software . . . . .	10
3.3	Dump of communication between the <i>HX300</i> and the <i>CE134</i> software .	11
4	Et cetera	12
4.1	Contact information . . . . .	12
	Terms and abbreviations	13
	References	14

# 1 Introduction

## 1.1 The *Standard Horizon HX300* floating handheld VHF radio

The *Standard Horizon HX300* floating handheld VHF radio can be programmed with extra VHF "user channels" as required. When adding "user channels" to the radio, please take great care not to transmit on frequencies on which you are not licensed to operate. The official frequency ranges for the *HX300* are listed as follows [9]:

**Transmit (TX):** 156.025 to 157.425 MHz

**Receive (RX):** 156.050 to 163.275 MHz

Actual use has proven that the unit is capable of receiving and transmitting on a wider frequency range, including frequencies in the 145 MHz amateur radio band. The actual unit on which this test has been performed, is labeled *HX300E*, serial number JB3B060xxx. Section 3.1 mentions possible bandwidth limitations in radios destined for the US market.

NOTE: When *reading* the memory contents from the *HX300* and other *Standard Horizon* radios, channels/frequencies outside the above specified frequency ranges have the kHz-portion zeroed out. E.g. user-programmed channel *L1* (Nordic pleasure craft channel 1 at 155.500 MHz) will download as 155.000 MHz.

It has not been determined whether this behavior is caused by radio firmware/EEPROM limitations or the PC-side *CExxx* PPS software.

## 1.2 The original HX300 programming interface

The programming interface of the *Standard Horizon HX300* utilizes a mini-USB connector which is also used for charging the radio. It should be noted that the communication between the PC and the HX300 does not actually take place using standard USB communication. A direct connection between the PC and the radio, using an ordinary USB/mini-USB cable will only provide charging of the HX300. Programming the radio will not be possible using an ordinary USB/mini-USB cable.

The original programming software for the HX300, named *CE134*, includes schematic which details the required parts, as prescribed by *Standard Horizon*:

**CT-172 cloning cable**, which hooks up to the mini-USB-like interface of the HX300.

**USB-62B cable**, which (1) adds a serial port via USB to the computer and (2) provides voltage level conversion to TTL levels (5V).

The *USB-62B* cable is easily available as it is commonly used also with *Yaesu* amateur radio transceivers [5] — hardly surprising, as the *Standard Horizon* brand is controlled by *Yaesu Musen Co., Ltd.*, well-known manufacturer of amateur, marine and air-band transceivers.

It should be noted that other interfacing options also exist, as detailed in section 2 of this document.




Figure 1: Original programming setup for the HX300 as described in the CE134 documentation. For reasons unknown, the CT-172 cable assembly seems somewhat hard to get hold of. No worries, there are several other options available.

## 2 The HX300 USB interface

Communication with the HX300 for programming purposes takes place using serial communication at 19,200 and 57,600 baud, utilizing TTL voltage levels at 5V.

The USB-62B USB cable assembly readily provides TTL voltage levels. A USB-62B-like cable assembly is available from *RT Systems, Inc.*, listed as the CT-62 [5]. The original *Standard Horizon CT-172* cable assembly seems to be a bit harder to get hold of. Luckily, the original CT-172 is not really required for programming the HX300 radio.

Other interfacing options include the *FTDI Basic Breakout* from *SparkFun Electronics, Inc* [7] and the *FTDI Friend* from *Adafruit Industries, LLC* [1] which will both provide the required TTL voltage levels and a serial port via USB. Similar TTL/serial port via USB breakout units (5V) are also available from *eBay* [3] at very reasonable prices.

Also, owners of the *Standard Horizon CT-99* cable assembly can easily use jumper wires to hook up to the USB-62B for programming the HX300. Either way, a mini-USB connector is required for connection to the HX300.




Figure 2: The HX300 mini-USB connection. Illustration from HX300 user's manual [9].



Figure 3: The Standard Horizon CT-99 cable assembly which will attach to the USB-62B.

## 2.1 A brief examination of the *HX300* mini-USB connector

*Standard Horizon* opted for a mini-USB connector both for charging and for programming the *HX300* radio. The charging takes place using the *Vcc* and *ground* lines of the mini-USB connector. It is important to emphasize that programming the radio does *not* utilize normal USB data transfers and that *a normal USB/mini-USB cable cannot be used to program the radio*.

The mini-USB connector contains five pins:

**Vcc** +5V DC. Used only for charging the *HX300*.

**Ground** Used for charging the *HX300* and as signal ground reference (GND).

**Data+** TX at the radio end (TTL signal levels at 5V).

**Data-** RX at the radio end (TTL signal levels at 5V).

**ID** Not used with the *HX300*.

The TX ("Data+") and RX ("Data-") lines as well as GND are required for programming the *HX300* radio. Note that the "Data+" and "Data-" notions only apply to the pin names in the mini-USB connector — they are not the actual signal names as used in a "proper" USB interface.




Figure 4: The pinout of the mini-USB connector. Note that wire colors may vary.

A mini-USB cable can probably be scavenged from the parts bin. It will need a slight modification as shown in figure 5.




Figure 5: The mini-USB connector about to face its final destiny. Note that wire colors may vary.

From here on, proceed either via *the CT-99 route* (if you already have access to the mentioned cable assemblies) or *the FTDI Friend route* (if you first need to go shopping).

## 2.2 Option 1: Using the *USB-62B* and the *CT-99* cable assemblies

For those who happen to have the *Standard Horizon CT-99* cable assembly around, the remaining process will be fairly straightforward. The *CT-99* is required for programming a number of fixed-mount *Standard Horizon* radios. It also happens to provide an easy means of hooking up to the *USB-62B* for accessing the TX DATA, RX DATA and GND lines.

The pinout of the *USB-62B* connector is identified in documentation accompanying interface units for certain *Yaesu* amateur radio products, including the *Yaesu FT-817/D* radio.




Figure 6: The *USB-62B* connector (female). The essential pins are labeled TX DATA, RX DATA and GND and reflect the signal names at the radio end of the cable.

Using a multimeter with the *CT-99* cable assembly, the pinout is easily identified. Figure 8 refers — note the notch and the orientation of the connector.

The *CT-99* should be plugged into the *USB-62B* which in turn should be plugged into a PC/USB port. At the *CT-99* end, refer to figure 8 for details on how to route the TX DATA, RX DATA and GND signal wires into the mini-USB connector which goes into the *HX300* radio.




Figure 7: The *USB-62B* connected to the *CT-99*, wired to the mini-USB connector which in turn goes into the *HX300*.






Figure 8: In this particular setup, BLACK=ground, WHITE=RX DATA, GREEN=TX DATA — signal names are valid at the radio end of the cable. The green, white and black wires belong to the mini-USB connector which goes into the HX300. Refer to figures 4 and 5 for a review of the mini-USB pinout.

### 2.3 Option 2: Connecting to the FTDI Friend (and the likes)

The FTDI [4] option is probably the least expensive route provided a USB-62B cable assembly (and/or a CT-99 cable assembly) is not already available.

FTDI interfacing options include the *FTDI Basic Breakout* from SparkFun Electronics, Inc. [7] and the *FTDI Friend* from Adafruit Industries, LLC [1] which will both provide the required TTL voltage levels and a serial port via USB, including easily accessible Windows, MacOS and Linux drivers. Similar TTL/serial port over USB breakout units (5V) are also available from eBay [3] at very reasonable prices.

It should be noted that several of the FTDI breakouts are capable of operating at both 3.3V and 5V levels. Refer to the device documentation regarding how to configure correct signal levels (5V).

The setup for programming the HX300 using a FTDI device is simple. The TX DATA, RX DATA and GND lines are required. Wiring details are described in table 1.




Figure 9: The Adafruit FTDI Friend hooked up to the PC (white mini-USB cable on the right) and to the HX300 (the three wires on the left leading to the mini-USB connector).

FTDI Friend signal name	Wire color	HX300 signal name	USB pin name
RX	Green	TX DATA	Data+
TX	White	RX DATA	Data-
GND	Black	GND	Ground

*Table 1: Wiring details. "USB signal name" does not imply actual USB signals, it is only used as a reference to figure 4. NOTE: wire colors may vary.*

### 3 HX300 programming software

#### 3.1 The CE134 PPS programming software

The *Standard Horizon* programming software for the HX300 is called CE134. It may or may not be available from various online resources as the software is normally made available to authorized *Standard Horizon* dealers only. There may or may not be different versions of the software for the USA (possibly bandwidth limited) and non-USA (not bandwidth limited) markets.

Several of the *Standard Horizon* radios available on the US market are known to be bandwidth limited. It has not been established whether this also applies to the HX300. The *Wide Band Programming Recovery Tool* may be able to allow extended bandwidth operation also on the HX300. This utility is available from *The Vertex Radio Group* site [8].

The original CE134 software will establish a handshake with the HX300 at 19,200 baud and continue the communication with the radio at 57,600 baud. The protocol seems to be identical to the protocol used with the HX851 radio, briefly described in [6].

In order to place the HX300 in programming/cloning mode, first switch the radio off — then connect the USB cable and keep the PRESET key pressed in while switching the radio on. The LCD display should indicate "CL" and move on to indicate "CP" once communication has been established with the programming software.




Figure 10: Screenshot from the CE134 PPS software.

## 3.2 DIY programming software

There is currently no known DIY programming software available for the *HX300*. The *CHIRP* project [2] may or may not support programming the *HX300* in present or future releases.

Readers who have in-depth knowledge of the programming protocol employed by *Standard Horizon* radios, including the *HX300*, are encouraged to forward these details to the author. Section 4.1 contains relevant contact information.

### 3.3 Dump of communication between the HX300 and the CE134 software

This excerpt shows some of the communication taking place between the HX300 and the CE134 programming software during a "read to PC" operation.

The "handshake sequence" occurs at 19,200 baud when the CE134 software sends the letter "P" to the radio. Once the radio responds with a "P", the CE134 software sends the ACMD:002 command and switches the baud rate to 57,600. At this moment the HX300 LCD display changes from "CL" to "CP". This is followed by a series of commands from the CE134 software — reading the memory contents at numerous EEPROM memory addresses.

PPP					
ACMD:002					
\#CMDSY					
\#CMDOK					
\#CMDSY					
\#CMDOK					
\#CEPSR	00	74			
\#CMDOK					
\#CEPSD	00	62			
\#CMDOK					
\#CEPRD	0080	02	60		
\#CMDOK					
\#CEPDT	0080	02	012C	1F	
\#CMDOK					
\#CEPRD	07FE	02	6C		
\#CMDOK					
\#CEPDT	07FE	02	012C	13	
\#CMDOK					
\#CEPRD	0000	10	6B		
\#CMDOK					
\#CEPDT	0000	10	FFFFFFFFFFFFFFFFFFFFFFFF		64
\#CMDOK					
\#CEPRD	0010	10	6A		
\#CMDOK					
\#CEPDT	0010	10	FFFFFFFFFFFFFFFFFFFFFFFF		65
\#CMDOK					
\#CEPRD	0020	10	69		
\#CMDOK					
\#CEPDT	0020	10	FFFFFFFFFFFFFFFFFFFFFFFF		66
\#CMDOK					
\#CEPRD	0030	10	68		
\#CMDOK					
\#CEPDT	0030	10	FFFFFFFFFFFFFFFFFFFFFFFF		67
\#CMDOK					
\#CEPRD	0040	10	6F		
\#CMDOK					
\#CEPDT	0040	10	FFFFFFFFFFFFFFFFFFFFFFFF		60
\#CMDOK					
\#CEPRD	0050	10	6E		
\#CMDOK					
\#CEPDT	0050	10	FFFFFFFFFFFFFFFFFFFFFFFF		61
\#CMDOK					
\#CEPRD	0060	10	6D		
\#CMDOK					
\#CEPDT	0060	10	FFFFFFFFFFFFFFFFFFFFFFFF		62
\#CMDOK					
\#CEPRD	0070	10	6C		
\#CMDOK					
\#CEPDT	0070	10	FFFFFFFFFFFFFFFFFFFFFFFF		63
\#CMDOK					
\#CEPRD	0080	10	63		
\#CMDOK					
\#CEPDT	0080	10	012C002000010000201001FFFF020102		1C
\#CMDOK					
\#CEPRD	0090	10	62		
\#CMDOK					
\#CEPDT	0090	10	01010101020100010001020115FFFF000		1F
\#CMDOK					
\#CEPRD	00A0	10	1A		
\#CMDOK					
\#CEPDT	00A0	10	FFFFFFFFFFFFFFFFFFFFFFFF		15
\#CMDOK					
(etc. etc.)					

## 4 Et cetera

### 4.1 Contact information

Readers who have in-depth knowledge of the programming protocol employed by *Standard Horizon* radios, including the *HX300*, are encouraged to forward these details to the author.

Contact information, web address, et cetera:

Torkel M. Jodalen  
Pb. 1036 Jeløy  
NO-1510 Moss  
Norway

Email → [tmj@bitwrap.no](mailto:tmj@bitwrap.no) (no technical questions, please).

Web → <http://www.annoyingdesigns.com/HX300>

Remember → Always have the appropriate amount of fun.

## List of abbreviations

**COM** Communications port.

**DC** Direct Current.

**DIY** Do-It-Yourself.

**EEPROM** Electrically Erasable Programmable Read-Only Memory.

**FTDI** Future Technology Devices International Ltd. <http://www.ftdichip.com>.

**LCD** Liquid Crystal Display.

**MHz** Megahertz.

**PC** Personal Computer.

**PPS** Personal Programming System.

**RS-232** A standard for serial communication transmission of data.

**RX** Receive.

**TTL** Transistor-transistor logic.

**TX** Transmit.

**USB** Universal Serial Bus.

**V** Volt.

**VHF** Very High Frequency (30 to 300 MHz).

## References

- [1] Adafruit Industries, LLC. FTDI Friend. <https://learn.adafruit.com/downloads/pdf/ftdi-friend.pdf>, 2014. Accessed: 2015-06-04.
- [2] CHIRP. CHIRP is a free, open-source tool for programming your amateur radio. <http://chirp.danplanet.com>, 2014. Accessed: 2015-06-06.
- [3] eBay, Inc. One Company - eBay, Inc. <http://www.ebay.com>, 2015. Accessed: 2015-06-02.
- [4] Future Technology Devices International Ltd. FTDI Chip. <http://www.ftdichip.com>, 2015. Accessed: 2015-06-06.
- [5] RT Systems, Inc. FT-817/D Radio Software. <https://www.rtsystemsinc.com/FT-817-programming-software-and-USB-cable-s/1927.htm>, 2014. Accessed: 2015-06-02.
- [6] Paul Sladen. Standard Horizon HX851E. <http://www.paul.sladen.org/toys/vertex/hx851e.html>, 2014. Accessed: 2015-06-06.
- [7] SparkFun Electronics, Inc. SparkFun FTDI Basic Breakout - 5V. <https://www.sparkfun.com/products/9716>, 2014. Accessed: 2015-06-02.
- [8] The Vertex Radio Group. Vertex Radio Group. <http://www.vertexradiogroup.net>, 2015. Accessed: 2015-06-06.
- [9] Yaesu Musen Co., Ltd. *HX300 Floating VHF FM Marine Transceiver Owner's Manual*, 2013 edition.



